⚠Warning
⚠ATTENTION: Not suitable for children under 36 months.
⚠ATTENTION: To be used under the direct supervision of an adult.



Children's Toy User Manual
I. Safety Warnings
1. This product is intended for children aged 3 years and older.
2. Do not allow infants or toddlers to play with this toy unattended, to prevent accidental ingestion.
3. Keep away from open flames and high-temperature environments.
II. Product Name
Children's Toy
IV. Model Number
39641243
V. Instructions for Use
1. Open the packaging and remove the toy.
2. Clean the surface before use.
VI. Precautions
1. Avoid prolonged exposure to direct sunlight or humid environments.
2. During use, regularly inspect for any loose components.
3. Do not use for purposes other than those specified.
VII. After-Sales Service
For quality-related issues, please contact customer service.