Product Manual

Usage Instructions

- Charge via hand crank, solar panel, or USB before outdoor use.
- Select AM/FM/shortwave; use headphones for private listening.
- Use flashlight and SOS alarm to signal rescue teams.

Precautions

- Avoid over-cranking; use hand crank and solar panel as specified.
- Keep dry; avoid impact, heat, and long direct sunlight.
- Test charging, radio, and alarm before trips.

Features

- Emergency power: hand crank and solar panel provide backup electricity.
- Device charger: 1200mAh battery and USB output support phone charging.
- Loud SOS alarm, flashlight, AM/FM/shortwave radio, and headphone jack.

FAQ

Q: How do I charge it? A: Use hand crank, solar panel, or USB.

Q: Can I listen privately? A: Yes, use the headphone jack.

After-Sales Service

- Terms are not specified; contact the seller for warranty or repair.
- Keep purchase records and package contents for service requests.

Safety Notices

- Use SOS alarm and flashlight responsibly; avoid pointing light into eyes.
- Do not open or modify the device; supervise children near it.
- In life-threatening emergencies, contact local rescue services first.